
EN XB-100 Horizontal Base



Mounting Instruction


Mount the base on the housing with the self threading screws. Line up with a square.

Earlier undrilled models

Move the machine label from the top of the machine to its side. On the 2000 series first remove the Info-label.

Mark the position for the first screw and drill. \varnothing 5.0 mm ($\frac{3}{16}$ ") for the 2000 series and Ø 4.3 mm for the 1200 series. Put one or two drops of oil on the screws when mounting on the 2000 series.

Mount the base with one screw and check the alignment with the square. Mark the remaining three holes. Remove the base and drill.



Warning!

Disconnect the machine from the power supply before commencing this job. Watch that the drill does not go too deep so that it hits the motor underneath.